

## **SCUFF PANELS** **Kenworth T660**

### **INSTALLATION INSTRUCTIONS:**

1. Position the Scuff Panel against the side of the truck.
2. Using the part as a template, mark the four mounting holes on each side.
3. Verify that the backsides of the locations marked are accessible and that there is adequate clearance.
4. Drill the holes with a 3/16" drill bit.
5. Secure the parts to the side panels with the provided hardware.

## **PANNEAUX ANT- ÉRAFLURES** **Kenworth T660**

### **INSTRUCTIONS D'INSTALLATION:**

1. Placez le panneau anti-éraflures sur le côté du camion.
2. En utilisant la pièce comme gabarit, marquez les quatre trous de fixation de chaque côté.
3. Vérifiez que l'arrière des emplacements marqués soient accessibles et qu'il y a suffisamment d'espace.
4. Percez les trous avec une mèche de 3/16".
5. Fixez les pièces aux panneaux latéraux avec la quincaillerie fournie.

## **PANEL DE DESGASTE** **Kenworth T660**

### **INSTRUCCIONES DE INSTALACIÓN:**

1. Coloque el panel de desgaste contra el lado del camión.
2. Usando la pieza como plantilla, marque los cuatro agujeros de montaje en cada lado.
3. Verifique que la parte de atrás de las localizaciones para agujeros marcados es accesible y que hay espacio adecuado.
4. Perfore los agujeros con una broca de 3/16".
5. Asegure las partes a los paneles laterales con los accesorios provistos.