

## CAB PANELS CAT CT660

### INSTALLATION INSTRUCTIONS:

1. Remove the factory skirting.
2. Remove the bracket that held the skirt in place at the back of the door.
3. Install the supplied bracket, as shown below, using the supplied 5/16-18 x 3/4" bolt, lock nut and washer.
4. Loosely assemble the front and rear bracket to the skirt using the supplied 10-32 hardware.\
5. Attach the skirt to the bracket that is installed to the truck and adjust all other brackets so that they sit flush up against the underside of the cab.
6. In locations where 5/16-18 nutserts exist in the cab (usually only driver side rear), attach the brackets to the truck using the supplied 5/16-18 hardware.
7. If no nutserts exist, attach the brackets to the truck using the supplied #14x3/4 self-drilling screws.
8. Tighten all hardware.

