

CAB SKIRT Peterbilt 579

INSTALLATION INSTRUCTIONS:

1. Hold the cab skirt to the inside of the lower door flange to check fit and location.
2. Hold the cab skirt to the outside of the door flange in the same location and mark the mounting hole locations.
3. Drill 5/16" holes in the locations marked.
4. Attach the cab skirt to the inside of the flange using the supplied 1/4-20 hardware.

JUPE DE CABINE Peterbilt 579

INSTALLATION INSTRUCTIONS:

1. Maintenez la jupe de cabine sur l'intérieur du rebord inférieur de porte pour vérifier l'ajustement et l'emplacement.
2. Maintenez la jupe de cabine à l'extérieur du rebord de la porte au même emplacement et marquez l'emplacement des trous de fixation.
3. Percez des trous de 5/16" aux endroits marqués.
4. Fixez la jupe de cabine à l'intérieur du rebord de porte à l'aide de la quincaillerie 1/4-20 fournieHold the cab skirt to the inside of the lower door flange to check fit and location.