

Installation Procedure:

1. Peel plastic from around all bolt holes.
2. Attach both brackets with the slots to the backside of the bug deflector. Do not tighten, as the brackets must slide freely.
3. Install the trim guard to the bottom edge to prevent scratching of the hood.
4. Place the bugshield on the hood directly behind the grille bezel or grab handle. Hold the bugshield in the desired position, making sure the bugshield is centered and parallel with the grille.
5. Mark all four bracket holes and the two end holes onto the hood.
6. Set aside the bugshield.
7. Drill 9/32" holes in all marked locations.
8. Tilt the hood forward and attach the bugshield to the hood using the supplied hardware.
9. Tighten the 10-32 screws on the face of the bugshield from step 2 and remove the protective plastic from the shield.
10. Clean with glass cleaner, if necessary.

*** NOTE: For some applications where the bugshield is cutout for a grab handle, it is advised that the rubber edging be installed around the cutout.***

