



## GRILL DEFLECTOR

### CAT CT660

Panelite, Inc. · 275 Industrial Road · Cambridge, ON N3H 4R7 · Phone: 519-884-8555 · Toll Free: 1-800-331-7952 · FAX 519-884-8553 · website: [www.panelite.com](http://www.panelite.com)

#### ***Installation Procedure:***

1. Apply masking tape to the section of the side hood where the hood meets the grill, where the grill deflector will sit.
2. Hold or tape the grill deflector in the desired position. Using a pen, transfer the holes from the grill deflector onto the masking tape.
3. Drill a small pilot hole in the center of each marked location. Using a 25/64" drill bit, drill through the hood in each location.
4. Using a 1/4" nut insert gun or provided tool, install the inserts in each hole.
5. Peel back the plastic from the mounting face of the grill deflector.
6. Using the supplied hardware, bolt the grill deflector in place using the supplied 1/4-20 bolt, lockwasher and washer.
7. Peel the plastic from the part and clean with glass cleaner, if necessary.