

CAB PANEL EXTENSION Western Star 49X Daycab

INSTALLATION INSTRUCTIONS:

NOTE: Cab panels must be installed prior to installing the cab panel extensions.

1. Peel the protective plastic around the bolt holes.
2. Install the panel, using the supplied 10-32 hardware to connect the panel to the cab panel but do not fully tighten.
3. Fasten the panel to the rear of the cab through the existing hole in the truck. Use the supplied ¼-20 hardware for this, while placing the nylon spacer between the panel and the cab of the truck.
4. Finish tightening all hardware.
5. Repeat the previous steps to install on the opposite side.
6. Peel the remaining protective plastic and wipe the panels with a soft cloth and glass cleaner if needed.