

Stainless Steel Accessories

MACK CH, SKIRT KIT

INSTALLATION INSTRUCTIONS

Sleeper:

1. Hold Sleeper Panel in place on truck, and mark (6) mounting holes.
2. Drill Sleeper Panel mounting holes, as marked in step 1, using a 7/32" drill bit.
3. Fasten Sleeper Panel to truck with (6) provided 10-32 bolts, nuts, and washers.

Cab:

4. Hold Cab Panel in place on truck with the back end of it butted-up against the Sleeper Panel, and mark (4) mounting holes.
5. Drill Cab Panel mounting holes, as marked in step 4, using a 9/32" drill bit.
6. Fasten Cab Panel to truck with (4) provided 1/4-20 bolts, nuts, and washers
7. Fasten Cab Panel to Sleeper Panel with (1) provided 1/4-20 carriage bolt. Use the provided 9/16" washer, then 7/16" washer, and locknut.

Extender:

8. Hold Extender Panel in place on truck, and mark (3) mounting holes.
9. Drill Extender Panel mounting holes, as marked in step 8, using 7/32" drill bit.
10. Fasten Extender Panel to truck with (3) provided 10-32 bolts, nuts, and washers
11. Fasten Extender to truck with (2) provided 10-32 bolts, nuts, and washers.
12. Repeat all steps for other side of truck.