

STAINLESS STEEL ACCESSORIES

LICENSE PLATE/SWING PLATE, HX520/620

INSTALLATION INSTRUCTIONS

Install may require 2 people

1. choose desired mounting location on bumper face
(top or bottom and driver or passenger sides)
2. loosen off two bolts on front face off bumper
3. remove protective plastic on the part from surface that will be resting against bumper face
4. slide the part between existing washer and bumper face.
5. Loosely tighten bolts to snug up the license plate holder assembly to the bumper, leaving some room for adjustment
6. Level off the license plate holder assembly with the top of the bumper
7. Finish tightening bolts
8. Remove remaining protective plastic from holder assembly
9. Remove the license plate bezel, insert license plate and reinstall the bezel onto holder.

