


Install Instructions

1. Remove clearance lights from the roof and attach supplied wiring harness extensions to the light harness', letting them hang out of the cab.
2. Drill out the inserts for the factory lights using a 25/64" drill bit. Install supplied 1/4-20 inserts into the holes using the instructions and tool supplied.




3. Feed the harness' through the bracket tubes. Fasten the brackets to the installed inserts using the supplied 1/4-20x1 hex bolts, lock washers and flatwashers according to their marked orientations as follows:

- 1 = Outside Right (passenger side)
- 2 = Inside Right (passenger side)
- 3 = Center Bracket
- 4 = Inside Left (driver side)
- 5 = Outside Left (driver side)

Daycab


- 6 = Outside Right (passenger side)
- 7 = Inside Right (passenger side)
- 3 = Center Bracket
- 8 = Inside Left (driver side)
- 9 = Outside Left (driver side)

4. Peel back the plastic coating from around all mounting holes on the sunvisor to prevent screw heads from pinching the plastic.
5. Once all the brackets are in place, set the passenger side visor onto the passenger brackets and fasten using the supplied 10-32 truss head bolts, washers and nuts. Do not fully tighten to allow for alignment and adjustment of visor brackets.




TEMPORARY INSTALLATION OF PASSENGER SIDE SUNVISOR
TO ACHIEVE PROPER ALIGNMENT AND POSITION


6. Install driver side sunvisor onto driver side brackets in the same manner.
7. When sunvisor has been installed and adjusted into desired position, remove sunvisor halves from the brackets.
8. Drill 3/16" holes into the truck cab through the two side holes on each bracket.



DRILL 3/16 HOLES INTO TRUCK
CAB THROUGH REMAINING TWO
HOLES IN BRACKETS




9. Remove brackets from the roof and apply a generous amount of the supplied silicone into and around all bracket mounting holes.




APPLY SUPPLIED SILICONE AROUND AND IN
ALL MOUNTING HOLES FOR THE BRACKET

10. Insert wire harness' through supplied rubber gasket slits and apply gaskets to cab, lining up bolt holes in the cab with those in the gaskets. Apply more silicone to the perimeter of the gasket, all bolt holes and the harness' area.



INSTALLATION OF RUBBER GASKET. APPLY SILICONE AROUND THE GASKET PERIMETER, IN AND AROUND ALL MOUNTING HOLES AND AROUND THE HARNESS


11. Re-mount brackets over rubber gaskets ensuring that the harness is threaded through the bracket tube. Do not tighten the top and bottom hex bolts and the #14 self-tapping screws.
12. Re-install sunvisor halves onto brackets. Once all hardware has been “snugged up” and sunvisor is in desired position, tighten all hardware.
13. Place symmetrical end support braces and tighten using supplied hardware.



INSTALLATION OF END BRACE

FASTEN END BRACE TO BRACKET USING 1/4-20 X 1 HEX HEAD BOLTS, 1/4 FLAT WASHERS AND 1/4-20 HEX NUTS.

USING 10-32 PAN HEAD SCREWS, #10 FLAT WASHERS AND 10-32 HEX NUTS, FASTEN END BRACE TO VISOR.



14. Install clearance lights using supplied 8-32 hardware, covering rectangular holes and brackets.
15. Remove protective plastic coating. If necessary, clean visor with glass cleaner and a soft cloth.